Electrical Parts

Contents

1 Troubleshooting 1
1-1 Winding Unit Alarms
1-2 Main Machine Alarm
2 Winding Unit 7
2-1 Layout of Electrical Equipment
2-2 Board Layout
3 Main Machine 9
3-1 Layout of Electrical Equipment
3-2 Principal Functions for Main Machine
4 Maintenance 14
5 Consumables 15

6 Chapter

Sec 1 Troubleshooting

1-1 Winding Unit Alarms

Alarm Recovery Method

- **Package alarms**

Alarm LED	Upper level light on
Status display	P*

* After checking the conditions of the end of the yarn on a package, press the illuminated reset switch (upper level).

- **Bobbin alarms**

Alarm LED	Lower level light on
Status display	b*

* After checking the conditions of the bobbins, press the illuminated reset switch (lower level).

- **Other alarms**

Alarm LED	Mid-level light on
Status display	Other displays

* If the alarm continues to sound, clear it by following the clearing procedure from the VOS screen.

Alarm Type & Description

Status Display	Alarm Type	Cause
01	Compiling Error	Program fault
02	Calculation Error	Program fault
03	Calculation Error (latch)	Program fault
04	Sequence Arithmetic Stop Error	Program fault
05	Carrying Error	Program fault
11	DISPLAY PCB Alarm	DISPLAY PCB error
12	SPLICER PCB Alarm	SPLICER PCB error
13	MIDDLE PCB Alarm	MIDDLE PCB error
14	BALCON PCB Alarm	BALCON PCB error
15	M/G CAN PCB Alarm	M/G CAN PCB error
60	DRUM BLD: Communication Timeout Between SPC	Communication error with UNIT-SPC
61	DRUM BLD: CPU Error	CPU error
62	DRUM BLD: Low Voltage	Low voltage
63	DRUM BLD: High Voltage	High voltage
64	DRUM BLD: Drum Sensor Error	Drum sensor input error
65	DRUM BLD: CS Sensor Error	CS sensor input error
66	DRUM BLD: Speed Deviation	Speed Deviation
67	DRUM BLD: Motor Overheat Protection (Thermistor)	Motor temperature high
68	DRUM BLD: Overload (Thermal)	Overload occurred
69	---	---

Status Display	Alarm Type	Cause
6A	DRUM BLD: IPM Fault	IPM fault
6b	DRUM BLD: CS Sensor Input Error	CS sensor input error
6C	DRUM BLD: CS Sensor Reverse Rotation Error	Drum rotated in reverse
6d	DRUM BLD: IPM Temperature Error	High IPM temperature, abnormal value
90	Air heater overheat alarm	Overheating error on air heater
91	Air heater disconnect alarm	Air heater is disconnected
92	Air heater temperature fluctuation alarm	Air temperature is fluctuating excessively from the set temperature
93	Temperature sensor disconnect alarm	Sensor that monitors the heater temperature is damaged or disconnected
94	Temperature control PCB communication alarm	Communication error between UNIT SPC and HOT SPLICER controller
95	CPU error on temperature control PCB	CPU error occurred on temperature control PCB
A1	Yarn Threading Error (system)	Yarn threading error Yarn break occurred right after drum start
A2	Yarn Threading Error (AD)	AD error
A3	Take-up Tube Supply Error	Take-up tube not ready
A4	Rear Package Not Processed	Doffing operation not possible due to package at rear
b0	Bobbin Supply Error	No bobbin supplied
b1	Lower Yarn Pickup Error	Lower yarn pickup error
b2	---	---
b3	Start Up Cut Alarm	Clearer cut occurs frequently
b4	---	---
b5	Yarn Count Alarm (UQC) Yarn Count Alarm (iQON) Yarn Count Alarm (YM) Yarn Count Alarm (KC)	---
b6	Pearl Chain Alarm (UQC) Pearl Chain Alarm (iQON) CLUSTER Alarm (YM) IPM Alarm (KC)	---
b7	Moire Alarm (UQC) Moire Alarm (iQON)	---
b8	CV Alarm (UQC) CV Alarm (iQON) CV Alarm (KC)	---
b9	Foreign Fiber Alarm (UQC) Foreign Fiber Alarm (iQON) Foreign Fiber Alarm (YM) DM Alarm (KC)	---
bA	Hairiness Alarm (UQC) Hairiness Alarm (iQON) SFI Alarm (YM)	---
bb	IPI Alarm (UQC) IPI Alarm (iQON)	---
bC	CMT Alarm (UQC) CMT Alarm (iQON)	---
bd	YF Alarm (UQC) YF Alarm (iQON)	---
bE	MFAlarm (UQC) MFAlarm (iQON) FF CLUSTERAlarm (YM)	---
bF	Other Alarms	---
bU	PPAlarm (UQC) PPAlarm (iQON) PAlarm (YM)	---

Status Display	Alarm Type	Cause
C0	Clearer Zero Adjustment Alarm	Clearer zero adjusting error
C1	Clearer Slot Jammed Alarm	Yarn waste clog in clearer slot
C2	Insufficient Cut Alarm	Clearer did not cut sufficiently
C3	Clearer Technical Alarm	Clearer technical alarm occurred * Refer to clearer alarm screen.
d1	Drum Wrapping Alarm	Drum wrapping occurred
E1	Splicer Home Position Sensor Alarm	Splicer operation error Splicer home position sensor alarm
E2	---	---
E3	Bal-Con Sensor Alarm Bobbin Sensor Alarm Package Diameter Detection Sensor Alarm	Bobbin (package) detection sensor error
E4	---	---
E5	---	---
E6	Package Rotating Sensor Alarm	Package rotating sensor error
E7	Retie Pipe Home Position Sensor Alarm	Retie pipe operation error Retie pipe home position sensor error
E8	PLC21 Alarm	PLC21 yarn travel detection error * Dirty receiver and transmitter windows, etc.
E9	Lower Yarn Sensor Alarm	Lower yarn sensor error * Dirty receiver and transmitter windows, etc.
EA	PC Sensor Alarm	PC sensor error Tension error detected
Eb	---	---
EC	Drum Lapping Detection Sensor Alarm	Drum lapping or winding detection sensor error
Ed	Traverse Sensor Alarm	Traverse sensor error
EE	Waste Yarn Detection Sensor Alarm	Waste yarn detection sensor error
EF	Tensor Operation Check Sensor Alarm	Tensor opener operation error Tensor operation check sensor error
EG	Suction Mouth Angle Sensor Alarm	Shutter mouth operation error Suction mouth angle sensor error
EH	Shutter Home Position Sensor Alarm	Shutter operation error Shutter home position sensor error
EJ	Bal-Con Home Position Sensor Alarm	Bal-Con operation error Bal-Con home position sensor error
EL	Peg Home Position Sensor Alarm Tray Eject Home Position Sensor Alarm	Peg operation error Peg home position sensor error Tray eject operation error Tray eject home position sensor error
En	Magazine Can Position Sensor Alarm	Magazine can operation error Magazine can home position sensor error
Eo	Yarn Guide Lever Home Position sensor Alarm	Yarn guide lever operation error Yarn guide lever home position sensor error

Status Display	Alarm Type	Cause
n1	Bal-Con Down Alarm	Bobbin detection sensor is left ON after drum start
n2	Bal-Con Up Alarm	Bal-Con up error
o1	Unconsumed Wax Alarm	Wax application failure
o2	No Wax Alarm	No wax
P1	Upper Yarn End Find Error	---
P2	Upper Double Yarn Alarm	Double yarn detected during upper yarn end find operation
P3	Sizing Alarm	Package diameter exceeds the specified value
P4	Package Brake Error	Package does not stop within specified time
P5	PJC Alarm (upper limit)	Too many yarn breaks/packages
P6	PJC Alarm (lower limit)	Too few yarn breaks/packages
P7	Package Half-locked Alarm	Bad package rotation occurred
r0	R/W module communication alarm	Communication error between UNIT SPC and R/W module
r1	Tag communication alarm	R/W module can't communicate with tag on tray
S1	Mis-splicing	---
S2	Splicer Cut	---
S3	Air Heater Temperature Change	Air heater is out of range for set temperature
T1	Tension Break Alarm	Frequent breaks in tension
T2	Traverse Error	Traverse error detected
T3	Tension Error (LOW)	Tension error (LOW) detected * Tensor is off, etc
T4	Tension Error (HIGH)	Tension error (HIGH) detected
u1	DC5V Power Supply Error	Line voltage error detected on DC5V power supply
u2	DC15V Power Supply Error	Line voltage error detected on DC15V power supply
u3	DC24V Power Supply Error	Line voltage error detected on DC24V power supply

1-2 Main Machine Alarm

Main Machine Fixer Call

Classification	Alarm Type	Signal Tower		Rotation Signal Warning		Machine Status	Cause
		Red	Yellow	Red	Yellow		
Machine	Emergency Stop	Flashing		Lit		Machine operation stopped	Emergency stop switch pressed
	Emergency Stop (Wire switch)						Wire switch is pulled
	Communication Error	Flashing (High speed)				Machine operation continued	Communication error occurred between devices inside machine
	Momentary Outage, or Blower Outage	Flashing				Machine operation stopped	Momentary outage or power outage occurred
	Air Down						Main air pressure low
Main control box	DC24V Input Power Alarm	Flashing				Machine operation stopped	Input fuse break (Main fiber SPC, expanded PCB or interface PCB)
	DC24V Output Power Alarm						Output fuse break (Main fiber SPC, expanded PCB or interface PCB)
	Blower Inverter Alarm						Blower inverter alarm occurred
	Conveyor, Blow Cleaner Trip						Motor breaker trip on conveyor or blow cleaner
	Dust Collector Thermal Trip						Motor breaker trip on dust collector
	Control Panel Overheat Alarm					Machine operation continued	High temperature inside control box, exceeds constant temperature level
	Cooling Fan Alarm						Cooling fan overheating
Blow cleaner	Blow Cleaner Travel Error Alarm	Flashing				Blow cleaner operation stopped	Blow cleaner travel error
Bobbin conveyor	Empty Conveyor Clog Detection	Flashing				Bobbin conveyor operation stopped	Empty conveyor clog occurred

Classification	Alarm Type	Signal Tower		Rotation signal warning		Machine Status	Cause
		Red	Yellow	Red	Yellow		
Water splicer	Water Tank Level Alarm	Flashing				Unit yarn splicing stop	Empty water tank
	Water Tank Pressure Down Alarm						Low water tank pressure
	Water Pipe Residual Air Alarm						Air bubbles present inside water pipe
AC/DC converter	Converter Error	Flashing				Operation stopped	Converter error
	Converter Communication Error					Operation continued	Converter communication error
	Converter CPU Error					Operation stopped	Converter CPU error
	Converter Output Short Error						Converter output short error
	Converter DB Circuit Error						Error occurred on regenerative circuit for converter
	Converter FET Damage						FET element damage inside converter
	Converter DB Resistor Overheat Error						Overheating error occurred on regenerative resistor for converter
	Converter DB Resistor Protection						Protective function on regenerative resistor for converter enabled
	Converter DB Resistor Break Detection						Break detected on regenerative resistor for converter
	Converter Output Voltage Error						Converter output voltage error
Span slave	Span Slave Output Short Error	Flashing				Machine operation stopped	Span slave output short error
	Span Slave Communication Error					Operation continued	Span slave communication error
Package conveyor	Package Conveyor Alarm		Flashing (High speed)			Operation continued	Package left unattended for extended period of time on package conveyor

Sec 2 Winding Unit

2-1 Layout of Electrical Equipment

Operation & Display Parts



Status display
(Alarm code display)
(Used for maintenance functions)

Maintenance LED (Green)
(Used for maintenance functions)

Operator call LED (Red)
(Lights up during alarm)

Operator call LED (Blue)
(Lights up when package is full and flashes for full package warning)

Maintenance button (Left)
(Used for maintenance functions)

Maintenance LED (Red)
(Used for maintenance functions)

Alarm reset button (Up)
(Alarm reset)
(Yarn threading operation)

Alarm LED (Up)
(Lights up and flashes during package alarm)

Alarm rest button (Center)
(Alarm reset)

AlarmLED (Center)
(Lights up and flashes during bobbin alarm)

Maintenance button (Right)
(Used for maintenance functions)

Alarm rest button (Down)
(Alarm rest)
(Forced bobbin ejection)

Alarm LED (Down)
(Lights up and flashes during bobbin alarm)

Unit operation switch
(ON during operation)
(OFF during operation stop)

2-2 Board Layout



Sec 3 Main Machine

3-1 Layout of Electrical Equipment

Main Control Box



(1) Clearer control box
(2) VOS III
(3) Stop button
(4) Start button
(5) Bobbin/Tray conveyor switch
(6) Blow cleaner switch
(7) Clean mode button
(8) Main switch
(9) Signal tower
(10) Cooling fan (Top)
(11) Cooling fan (Bottom-right)
(12) Cooling fan (Bottom-left)
(13) Package conveyor start button
(14) Blower inverter
(15) AC reactor
(16) Noise filter
(17) DC control power supply
(18) Gateway PCB
(19) PCB for main fiber SPC
(20) Expanded PCB for main fiber SPC
(21) PCB for power distribution
(22) Circuit breaker
(23) Magnet contactor
(24) AC/DC converter
(25) Interface PCB
(26) Circuit breaker
(27) Motor breaker
(28) Magnet contactor
(29) Connectors for machine wiring connections
(30) T1 trance
(31) Noise filter
(Optional [CE specifications])



VOS III



[Rear view]

(1) VOS CPU board
(2) MCU (Machine Control Unit) board
(3) Compact flash
(4) DC control power supply (for MCU)
(5) DC control power supply (for VOS)

Unit Duct



(Length of 1 span)

(1) Span slave print circuit board
(2) PCB for branching communications
(3) Repeter print circuit board
(4) Power supply branch connectors (winding unit)
(5) Power supply branch connectors (dust collector [option])

3-2 Principal Functions for Main Machine

Machine Operation & Stop Controls

They control the overall start and stop operations for the machine.

Machine Alarm Detection & Support Method Display

The alarm is detected, the machine and devices are stopped, and the alarm location is displayed.
When an alarm occurs, the tower signal and rotation signal warning notify the surrounding personnel, and a picture of the problem location and the support method are displayed.

Machine Operation Status Display

The signal tower on the main control box and the out-end rotation warning signal notify surrounding personnel about the machine operation status.



[Signal Tower on Main Control Box]
This tower notifies the surrounding personnel about the general alarms for the machine.

	Lit	Flashing	
		At 0.2 second intervals	At 2 second intervals
Red	AD error	Communication error	Fixer call*
Yellow	---	Operator call*	---
Green	Operating	---	Stop during operation due to clean mode (Cycle stop)

* Refer to Chapter 6, 1-2.

[Out-end Rotation Warning Signal of the Winding Unit (Link Coner, Bobbin Tray)]
This rotation warning signal notifies the surrounding personnel about the alarms related to the CBF.*

	Lit	Flashing	
		At 1 second intervals	At 2 second intervals
Red	- CBF error - Steam setter problem	- Bypass line full - Bypass line 2 full	- Emergency stop - Spinning frame problem
Yellow	- Bypass line 1 operator call - Bypass line 2 operator call - Bypass line 1 full - Bypass line 2 full - Parts feeder bobbin empty - Parts feeder hoist at upper end	---	---

* Refer to the Chapter 7 (VOS) for further details on the alarms.

Blower Control

The blower control drives the blower motor at the frequency set on the VOS.

During machine standby	Blower speed during machine standby
During startup sequence	Operates at upper limit setting for blower speed
During machine standby	Operates at lower limit setting for blower speed

Tray Conveyor & Bobbin Conveyor Control

This control drives either the bobbin conveyor (Magazine Type) or the tray conveyor (Bobbin Tray type) using the bobbin / tray conveyor switch on the switch panel located in the main control box.

* There is also a drive switch on the out end side for the bobbin conveyor.
* The tray conveyor controls the motor mounted on the CBF side using the CBF control box.



Blow Cleaner Control

The drive for our in-house made blow cleaner is controlled using the blow cleaner switch on the switch panel located in the main control box.
Intermittent operation is also possible.

* Intermittent operation is standard on equipment with 36 winding units or less, and optional on equipment with 38 winding units or more.

Dust Collector Control

There is a dust collector system for each span.
It is controlled using the dust collector operation switch for Span No.1.



Dust collector operation switch

Package Shutter Control

The product type is set using the package conveyor product setting knob. Pressing the start button opens the corresponding shutter for the product type.

* The product type for each span is set on the VOS.

Package Conveyor Control

The package conveyor is controlled using the package conveyor operation switch located on the back side of the main control box. The LED for the switch lights up during drive cycle operation.

* When equipped with a package shutter, the package conveyor is driven after the package shutter operation.



[Manual Stop]
Pressing the switch again during drive cycle operation stops the operation.

[Auto Stop]
Operation automatically stops when the package detection sensor located on the end of the machine does not detect any package for a certain amount of time.

* The auto stop time varies depending on the machine length.

Tray Level Control

This function stops and re-starts operation for the winding unit per span, depending on the supply bobbin status of the winding unit. The tray detection sensor attached to each span detects the bobbin supply status.

* This function comes standard with the Bobbin Tray device and is optional on the link corner device.

* The criteria for the auto stop and restart operation for the winding unit are set on the VOS.

Sec 4 Maintenance

Main Control Box

- **Inspection & Cleaning**

The temperature inside the main control box will increase if yarn waste, cotton fly or other contaminants have built up on the box's filter. This temperature increase can reduce the life of the electrical components or damage them.
In addition, the VOS panel may rise or pop up if the pressure inside the box increases.

Frequency	Item	Guideline
Monthly	Filter	- Remove the side cover of the main control box and clean from the inside part of the cover using an air gun, etc. * Loosen the seven fixing bolts, and remove the side cover. - Check for clogging



Blower Inverter

Refer to the inverter instruction manual for details.

1. **Remove the detachable terminal with parameter back-up function from the new inverter.**
2. **Turn off the main switch on the main control box.**
   Wait until the inverter CHARGE lamp goes out.
3. **Remove the detachable terminal with parameter back-up function from the damaged inverter.**
   It is not necessary to remove the cable connected to the detachable terminal with parameter back-up function.
4. **Replace the damaged inverter with the new one and attach in original locations.**
5. **Attach the detachable terminal with parameter back-up function.**
6. **Check there are no shorts or earth faults with the circuits connected to the inverter.**
7. **If there are no problems, turn ON the main switch in the machine control box.**
8. **Test run the machine and check there are no problems with functionality.**

Sec 5 Consumables

Main Switch UVT (Undervoltage trip device)

The main switch is equipped with a UVT (Undervoltage trip device) as an accessory device.
This device trips the main switch to prevent a malfunction or machine damage while recovering from the power outage, or when the factory experiences a drop or low electrical power voltage.

The UVT has a product lifespan. If the life of the UVT is exceeded, it will stop tripping even when the trip conditions are met.
(UVT function lifespan: 3500 trips)

* When the operator turns OFF the main switch, this operation does not impact the lifespan.

If the main switch does not trip during a power outage, replace the UVT with a new device.

* For further details on the replacement procedure, refer to the “UVT Device Installation Guide” that is provided with the UVT.